



Pattern Information

Date: 11.9.2022
 Pattern Type:
 Pattern Difficulty:
 Pattern Designer:
 Pattern Volume (ml): 22,25

Surface Information

Surface Type: Synthetic
 Surface Brand: Brunswick Pro Lane
 Age:

Pattern Parameters

Pattern Number:
 Pattern Name: Rengaspalveluturnaus VI
 Mode: Clean & Oil
 Forward Speed: Heavy Clean (Envoy)
 Start Cleaner Spray: 0
 Start Squeegee: 0
 Start Oiling: 6
 Split Pattern: No

Supplies Information

Lane Cleaner:
 Cleaner Mixture Ratio: 7 : 1
 Cleaner Transition Distance: Authority22
 Cleaner Spray End Distance: 53 Envoy
 Lane Conditioner: Logic

Notes Rengaspalvelu VI

	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
Zone End Distance	12	19	24	29	40			
Zone Ratio	L 2,5 : 1	2,7 : 1	2,1 : 1	1,7 : 1	### : 1	### : 1	### : 1	### : 1
	R 2,5 : 1	2,7 : 1	2,1 : 1	1,7 : 1	### : 1	### : 1	### : 1	### : 1
Zone Volume	13,29	5,47	2,50	0,99	0,00	0,00	0,00	0,00

ZONE	7 Pin Side																	Board Number																	10 Pin Side																
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1												
1	35	35	35	35	35	35	44	53	62	71	80	89	95	95	95	95	95	95	95	95	95	95	95	95	95	95	95	89	80	71	62	53	44	35	35	35	35	35	35	35											
2	24	24	24	24	24	24	30	36	42	48	54	60	69	69	69	69	69	69	69	69	69	69	69	69	69	69	60	54	48	42	36	30	24	24	24	24	24	24	24												
3	18	18	18	18	18	18	22	26	29	32	35	38	41	41	41	41	41	41	41	41	41	41	41	41	41	41	38	35	32	29	26	22	18	18	18	18	18	18	18												
4	8	8	8	8	8	8	10	11	12	13	14	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15										
5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0										
6																																																			
7																																																			
8																																																			

